




# Guide

# QUICK START GUIDE



- Turn ON/OFF by pressing the  $\ensuremath{\mathfrak{O}}$  Button for 3 seconds.
- If the speaker makes a beeping sound, this means the speaker needs to be charged.

#### PAIRING SPEAKER WITH BLUETOOTH ENABLED DEVICE • Turn ON "Bitty Plushies" speaker as indicated above.

- A blue LED light will light up then flash quickly, indicating it is in pairing mode.
- In your device's Bluetooth menu, locate and select "Bitty Plushies".
  - A tone will sound when pairing is complete.

# CONNECTING TO MULTIPLE DEVICES • Only 1 device can be connected

within range.
• To connect a different device in the same range you must first disconnect "Bitty Plushies" from

current connected device.

- PAIRING 2 SPEAKERS TOGETHER

   Make sure no "Bitty Plushies" are
- connected to any device. If so, disconnect.

   Power on each speaker one at a time.

   Double click 🖒 Button on the 2nd
  - Double click <u>U</u> Button on the 2nd speaker. You will hear a chirp sound, then the opposite speaker will make a short connect sound. (If you do not hear connect sound, double click the opposite speaker <u>U</u> Button)
     Connect as normal, only 1 "Bitty

 Connect as normal, only 1 "Bitty Plushies" will now show up in your Bluetooth settings.

#### BATTERY

Your Bitty Boomer Plush speaker comes with a built-in rechargeable battery. Prior to using it for the first time, it is recommended completely charge the battery.

When the battery is fully discharged. the unit will require a minimum of 30 minutes of charging before speaker function or Bluetooth music streaming can resume.

## CHARGING INTERNAL BATTERY

Insert the USB-C end of charging cable into speaker port located on back of speaker. Plug the USB end of charging cable into a USB computer port or USB plug/adapter. Once fully charged the LED indicator light will turn off.

#### PRODUCT SPECIFICATIONS

- POWER RATING: PO = 1X3W \*TRANSMITTING FREQ :
- 20HZ-20KHZ
- THD: <1%
- S/N: >80DB
- SPEAKER PARAMETER: 3W
- BATTERY: 3 7V/300mAH
- BLUFTOOTH VERSION: V5.3.

### PLUSH MATERIAL

- 100% POLYESTER OUTER **FABRIC**
- 100% POLYESTER FIBER INNER FILLING



Warning: To reduce the risk of fire or electric shock, do not expose this speaker to rain or moisture (including swimming pools or objects filled with liquids, such as vases or drinks). Warning: Your speaker has an internal rechargeable battery. Improper usage may result in the speaker becoming hot, ionite, or bust and cause injury if exposed to conditions of abuse.

Important Safety, Instructions: 1. Always read safety and operation instructions before use. Retain instructions for later reference, 2.

For indoor use soft, but not expose; seeker to last, in residence of humbly, 2. Do not leave ablested extensions for later to seeker to last, in resident cases and the seeker to last the seeker to l

LIMITED WARRANTY. Bitly Boomer! Fabricuse Innovations Inc. warrants to the first consume purchaser that this product, when shapped in a singual acchainer to the original purchaser, will be fine from decive workmaning and materials for one year and shapped in a singual and materials for one year and the shapped in the product of the product of regulates the effective product or part feword aft to charge to be purched for the shapped of the product from the additional excluded iterrity and for the time periods described.

The warranty described product in the product from the additional excluded iterrity and for the time which has been altered or morphism in described the product from the additional excluded iterrity and for the product from the

The warranties described herein shall be the side and exclusive warranties grained by Bilty Boomers' Fabricuse Innovations Inc. and shall be the sole and exclusive remotify available to the purchase corrections of defects, in the manner and for the period of time described herein, shall consistent complete falliment of all liabilities and responsibilities of Bilty Boomers' Fabricuse Innovations Inc. and state of the product of the produc

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Fabrique Innovations Inc./ Bitty Boomers is under license. Other trademarks and trade names are those of their respective owners.

FCC Warning: This device complex with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device way not cause in armini indirestore, and (2) this exercior must accord any miterioriens received, including interference has not accordance in the received of the received and form the received and form to comply with the limits for a Class Biglid device, postaget to provide rescendite protection against human digital device, postaget the part of the TCC Rules. These elimina end edigated to provide rescendite protection against human digital device, postaget to provide rescendite protection against human digital device, postaget the part of the TCC Rules. These limits are designed to provide rescendite protection against human digital device, postaget the part of the TCC Rules. These limits are designed to provide rescendite protection and accordance with the instruction, may cause harmful interference to rate of the provided of

This day to be an unit of substitution of the property of the

© 2024, Fabrique Innovations Inc., © 2024 Bitty Boomers • Distributed by Fabrique Innovations Inc., New York, NY 10018 • 800-511-1595 • All Rights Reserved • Made In China